

## ASTRON CONCRETE PRODUCTS



Making Tomorrow Stronger

www.astronspacers.com

Office: 9961915552

e-mail: mais remail: mais remai

## **Current Ranges Are:**

Single Cover Spacers - Single Cover Spacers Are The Most Basic Form Of Spacers In Used In GeneralConstruction Filed

Multi Cover Spacers - Multiple Cover Spacers Are Widely Used For Infrastructure And Pre CastingWorks.

Heavy Duty Spacers - Heavy Duty Spacer Are Used In Members With Very High Reinforcement Load E.G.Heavy Rafts Or Footings. (Presently It Is Manufactured Against The Requirements)

Spacers Are Used To Ensure That The Specified Cover To The Reinforcement In Concrete Structures And Structural Elements Is Maintained Both Before And During Concreting. We Offer You The Ideal SpacerFor Every Application:

High Compressive Strength, No Deformation In Heat Or Cold, Concrete Cover Accurately Maintained. Spacers Remain In Position During Formwork Erection And Concreting. Ideal For Impermeable Concrete, No Hairline Cracks Between The Spacer And The ConcreteTested According To Din 1048.

The Following Points Are To Be Noted When Selecting Spacers:

- Spacer Loading Due To the Weight of The Reinforcement And Additional Loads E.G. During Concreting, Fixing And Erection Work
- Diameter And Location Of The Reinforcement Wall/Slab
- Type Of Reinforcement Single Bars Or Mats
- Type Of Fixing Without Tying Wire, With Tying Wire, With Steel Or Synthetic Clips
- External Influences Affecting The Concrete, Such As Pressure, Temperature, Chemical Attack, Alternating Moisture Penetration, Fire And Corrosion
- Possible Imprint Left By Spacers On The Concrete Surface Exposed Concrete
- Concrete Surface Finishing
- Simple, Rapid And Economical Fixing Use Bar Spacers If Possible Spacers Are Used To Ensure That The Concrete Cover Specified For Structures And Structural Elements Made Of Reinforced Concrete IsAdhered To, Both Before And During Concreting.
- High Compressive Strength, No Deformation In Heat Or Cold, The Required Concrete Cover Will BeAccurately Retained
- The Spacers Remain In Position During Erecting The Formwork And Concreting
- Extremely Suitable For Impermeable Concrete, No Hairline Cracks Between The Spacer And TheConcrete Fire Resistant

Head Office :

Building No. 15/468, Kaipoorikkara, Marampally P.O. Aluva, Ernakulam Dt., Pin-683105 GSTIN: 32ACAPU4583C1ZS Ph: 996915554, 9961918889



