#### Make A Healthy Living, A Way Of Life





## COMMERCIAL OIL MAKER MACHINE MANUAL CUM WARRANTY CARD

**Congratulations** 



SH - 2000

#### Dear Customer,

**Our Heartiest Welcome Goes** 

To You. Thanks For Being
A Proud Customer Of Our
Unique And Ever-expanding
Line Of Products.
Our Products Is Engineered
To Perfection, Assembled
With At Most Care As Multilevel Quality Control System
To Ensure Trouble Free Operation For Years To Come.
please, Read The Instructions
In The Manual Carefully And
We're Honoured To Haye

You With Us Always!

"Destination of Purity"



MODEL : SH - 2000

TYPE : COLD PRESS / HOT PRESS

IN PUT VOLTAGE : 220-240 VOLT AC

TOTAL POWER : 2000 WATT

MOTOR POWER : 1.14 HP

POWER CONSUMPTION : 2 UNIT / 1 HRS

RPM : 76 ROTATION PER MINUTE

CAPACITY : 20-25 KG / HRS (ACC. TO MATERIAL SIZE)

KEEP WORKING : 10- 12 HRS CONTINUES

WEIGHT : 140 KG (APPROX)

SIZE : 41(L) \* 22(W) \* 48(H) INCH

WARRANTY : 1 YEAR\*





- 1. Hopper
- 2. Squeezing Tube
- 3. Squeezing Rods
- 4. Slug Band
- 5. Brush
- 6. Oil Collector Tray
- 7. Oil Collestor Mug
- 8. Oil Stainer
- 9. Hand Gloves
- 10. Power Cable
- 11. Installation Tools
- 12. Heater
- 13. Oil Cover
- 14. Wasers
- 15. Screw Driver
- 16. T-Allankey

4

### **Setting Instruction Chart [Waser]**

Seeds	Rod(Screw) Waser(mm) Number		
Ground nut	1/2	8.5 mm	
Sesame	2	9 mm	
Mustard	2	9 mm	
Sunflower	2	5 mm	
Safflower	2	5 mm	
Almond	1	8.5 mm	
Coconut	1	8 mm	
Walnut	1/2	8/8.5 mm	
Flaxseed	2	9 mm	
Neem	1/2	8/8.5 mm	

#### 5 Installation

Before using the machine read the instruction carefully relating to the performance and operation of the machine.

Machine Should be plug in separate switch and should be provide earth connection to the machine.

The squeezing ROD should be inserted in the squeezing holder and then insert the squeezing tube in the holder fitting as per below instruction.

Step 1 : Insert waser on rod as per Setting Instruction chart on page no. 4.

Step 2: Insert Rod.

Step 3: Insert the tube on rod.



Step 4 : Rotate It Anticlockwise and tight it with hammer.



### **6** Installation

Step 1: Fit the heater on squeezing tube and tight the bolt.



Step 2: Fit the heater plug.



Step 3: Fit the oil tray.

Step 4: Fix the hopper.

Step 5: Switch on the heater and set the temperature according to temperature chart on page no. 7.

# 7 Temperature Required For Seeds

Seeds	Temperature	
Ground nut	190°-220°c	
Sesame	200°-250°c	
Mustard	180°-200°c	
Sunflower	180°-200°c	
Safflower	180°-200°c	
Almond	180°-220°c	
Coconut	150°-180°c	
Walnut	180°-230°c	
Flaxseed	100°-200°c	
Neem	180°-200°c	

**Note:** It's just standard temperature according standard seeds.

Its variable upon seeds moisture.

So, you can also set the temperature as per your experience about this machine.

### **8** Pre Process



### How to set the Temperature

Step 1 : Set The Temperature Which You Have To Extract

Step 2: Press 2 For 3 Sec Than Display Will Show SP1

Step 2A: Press 2A Decrease The Temperature

Step 2B: Press 2B Increase The Temperature

Step 2C: Press 2C To Save The Temperature

**Step 3: Further Press 2 For Finish The Process** 

### **9** Pre Process



**Step 1**: Feed the seeds into the hopper.

#### **10 Process**





After reached the temperature switched on the squeezer button rotate the red knob anti clockwise.

#### Step 1 : Start the machine(Squeezer)

- Note: 1. Don't touch your hand in squeezer rod and tube. While machine is running it will burn your finger.
  - 2. During process do not enter any hard part or finger on hopper.



**Step 1**: After Complete the process switch off the heater.

Step 2: Switch off the squeezer button

**Step 3**: Remove the hopper

#### ★ Must wear glove below steps

Step 1: Remove the Heater.



Step 2 : Open the Squeezing tube, For That Rotate Clockwise by tools.



#### ★ Must wear glove below steps

Step 1: Switch on the Squeezer button for remove the squeezing tube.



Step 2 : Remove the tube(After switched on the squeezer button tube will automatically Come out)

Step 3: Remove the rod.



Note: Clean the tube and rod properly. Using hot and cold water and using the brush clean the front side of tube properly. Otherwise rod will didn't insert the tube.

### अब तो जागो, रिफाइंड ओइलसे भागो



#### शुद्ध तेल के फायदा

८० प्रतिशत रोग जो वायु से उत्पन्न होते है, वह नियत्रण में रहते है | रोग प्रतिकारक शक्ति बढ़ता है |

जोंडो के रोग में अंत्यंत लाभदायी है |

हदय से जुड़े रोगो का भय घटाता है |

) केन्सर को रोकने में मदद करता है | ) कोलेस्टॉल के लेवल को निंयत्रण में रखते है |

दांत को मजबूत करता है |



#### **BENIFITS OF PURE OIL**

80% disease which is created by gas controlled.

Boost immune system.

It is beneficial in joint disease.

Reduces risk of heart diseases..

Helps to Prevent cancer.

Helps to maintain cholesterol leyels.

Increase the pulse of the tooth.



#### रिफाइंड तेल यानी जहर

बेकार तेल और पामोलीन तेल को केमीकल प्रोसेस से तैयार होता है जिसमे कोस्टिक सोडा, हेक्जेन जेसे खतरनाक केमीकल का इस्तेमाल होता है | जिसे आप रिफाइंड ऑइल कहते है | जिसे खाने से केन्सर, हदयरोग, जोड़ो का दर्द, गेस, एसिडिटी, कब्जीयात इत्यादि रोग होते है |



#### **REFINED OIL MEANS POISON**

Refined oil Means Poison~Crude oil & Pamoline oil are being prepared with help of chemical processing containing CAUSTIC SODA & HEXANE which you are calling it has a refined oil.~Which leads to CANCER Arthritis and Several other Disorders.

OIL OUTPUT					
Nuts	દાણા	बीज		Yield	
Groundnut	મગફળી	मूंगफली		40 – 45 %	
Sesame	તલ	तिल		42 – 52 %	
Sunflower	સૂર્યમુખી	सूरजमुखी		18 – 25 %	
Mustard	સરસવ (રાઈ)	सरसों		25 – 35 %	
Almond	બદામ	बादाम		40 – 45 %	
Coconut	નાળિયેર	नारियल		45 – 55 %	
Walnut	અખરોટ	अखरोट		30 - 40 %	
Soyabean	સોયાબીન	सोयाबीन		10 – 14 %	

Note: Oil yield depends on seeds quality only & Capacity depend on seeds size

DATE OF PURCHASE:	
NAME OF PURCHASER:	6660
BILL / INVOICE / CASH MEMO NO. :	20000
DEALER'S STAMP & SIGNATURE :	18000

This warranty is not valid if above information is not duly filled in

We warrants this machine to be free from defects in materials and workmanship under normal use for a period of one(1) year from the date of purchase, as evidenced by the purchase receipt.

During the warranty period We shall repair the machine if defective. This warranty is limited to the purchaser and is not transferable.

\*One year warranty only for electric motor & temperature controller\*.

#### SHREEJA HEALTH CARE PRODUCTS

Regd. Office : 26, Ground Floor, Ratnasagar Apartment, Near Varachha Police Station, Surat - 395 006, Gujarat, India

> Email: shreejahealthcare@gmail.com Website: www.shreejahealthcare.com